

# SIMPLEX+ QUICK GUIDE

QGSP55000371EN

Sensitivity Indicator

Target ID

\*Left side navigation in notch discrimination and mode selection  
\*Change the value of any setting.

Pinpoint/Confirm Button:  
\*Pinpoint: Press and hold down on detection screen.

\*Confirm:

1) Ground Balance Function:  
Press and hold to auto ground balance while in the ground balance setting (  ).

2) Reject/Accept Targets:  
Press once to reject or accept targets while in notch discrimination setting (  ).



Target ID Scale

ID Notches  
(Groups of 5 IDs)

Modes  
(All Metal/Field/Park/Beach)

Depth Indicator

Battery Indicator

\*Right side navigation in notch discrimination and mode selection  
\*Change the value of any setting.

Sensitivity Up

Settings Button:  
Each time you press it, the next setting on the bar will be selected and its value will be displayed on screen.

\*On/Off: Press and hold down for about 3 seconds.

\*Sensitivity Down: Press one by one.



## SETTINGS:



Volume: (4 levels, change using + and -).



Ground Balance: Pump the coil up and down while pressing the Pinpoint/Confirm Button to ground balance automatically.



Iron Volume: Adjusts or turns off the volume of the low iron tone (3 levels, change using + and -).



Notch Discrimination: Eliminate unwanted metals from detection such as trash. Each box represents a group of 5 IDs Any combination of these boxes can be rejected or accepted.

### Automatic:

- 1) Swing the search coil over the metal you want to eliminate. The box that represents the group of IDs for that metal will be highlighted in black.
- 2) Press the confirm button.

### Manual:

- 1) An X and a check mark will appear on screen along with a small arrow cursor underneath the ID bar at the top of the screen.
- 2) Move the arrow cursor using the plus (+) and minus (-) buttons and select the box that includes the ID you want to eliminate.
- 3) Press the confirm button. The box will be highlighted in black.



Frequency Shift: Eliminates EMI (3 levels, change using + and -).



Wireless: 0=Off / Channels 1-5 (change using + and -).



Vibration: On/Off (change using + and -).



Brightness: Adjusts the LCD and keypad backlight. 0=Off / 1-4 / A= Auto (lights up only for a short period of time when a target is detected or while navigating the menu and then it goes off).



LED Flashlight: On/Off (change using + and -).

Just turn your detector on, ground balance if you need to and start swinging your coil. Happy metal detecting with the SIMPLEX+!  
For more details, please read the user manual.